


Switched (RCM-O) Connectivity Diagram

Switched



Temperature Sensor



Temperature, Air Flow Humidity, & Dew Point



RSD Remote Display

Static IP Address for set-up and configuration

Optional Remote Sensors Connect via RJ12