

# Satellite Switched (RS2) Connectivity Diagram

Satellite Switched



Connect to: RSMINI,  
RSE, RSO, RCX, RSM,  
RCM OR RCU



Temperature  
Sensor



Temperature, Humidity,  
& Dew Point Sensor

Optional Remote Sensor Connect via RJ12