


Environmental Monitoring + Display (RSE2X16) Connectivity Diagram

Optional Remote Sensors - Connect via I/O Port



Door Position Sensor



Smoke Alarm Kit




Water Sensor



Power Fail Monitor

RSE2X16



Temperature Sensor



Temperature, Air Flow Humidity, & Dew Point

Optional Remote Sensors Connect via RJ12

Static IP Address for set-up and configuration



DLink® Web Enabled Camera

ETHERNET

ETHERNET

ETHERNET

ETHERNET

ETHERNET