

Environmental Monitoring + Relays (RSO) Connectivity Diagram

Optional Remote Sensors - Connect via I/O Port



Door Position Sensor



Smoke Alarm Kit



Water Sensor



Power Fail Monitor

RSO



Temperature Sensor



Temperature, Humidity, & Dew Point Sensor

Optional Remote Sensors Connect via RJ12

Static IP Address
for set-up and
configuration



DLink® Web Enabled Camera

ETHERNET

ETHERNET

ETHERNET

ETHERNET

ETHER-