


Environmental Monitoring + Relays (RSO) Connectivity Diagram

Optional Remote Sensors - Connect via I/O Port



Door Position Sensor



Smoke Alarm Kit




Water Sensor



Power Fail Monitor

RSO



Temperature Sensor



Temperature, Air Flow Humidity, & Dew Point

Static IP Address for set-up and configuration



DLink® Web Enabled Camera

Optional Remote Sensors Connect via RJ12

ETHERNET

ETHERNET

ETHERNET

ETHERNET

ETHERNET